

How to replace your CROSS™ style refill

www.reMARKablepens.com

To refill this pen, simply twist and firmly pull it apart at the center band. This will expose a plastic top inside that twists counter clock-wise allowing you to pull out the spent ink cartridge. Drop the new refill into the pen and secure it by turning it clockwise as far as it will go and push the pen back together.